

BREW EXPRESS™

OPERATION GUIDE

model no. BE-112



by LANCE LARKIN™

CONTENTS

1. Safety	1
2. Features	2
3. Controller Functions	3
4. Start Up	4
5. Operation	5
6. Maintenance	6
7. Troubleshooting	7
8. Parts & Service	8
9. Warranty & Registration	9

IMPORTANT:


Please read and follow instructions carefully before starting your BREW EXPRESS™ in-the-wall COFFEE SYSTEM.

 **WARNING**

The BREW EXPRESS™ dispenses extremely hot water. Hot liquids may cause severe burns if it contacts skin. Use extreme caution when handling hot liquids dispensed by the BREW EXPRESS™. KEEP HANDS AWAY FROM SPRAY HEAD, BREW BASKET, CARAFE OR MUG DURING BREW CYCLE

- DO NOT use carafe or mug that is cracked or damaged.
- DO NOT remove the brew basket while brewer is in operation
- DO NOT place carafe in microwave or place on stove top

FEATURES



CONTROLLER FUNCTIONS

Display Panel

AM/PM Indicator

Indicates AM or PM for clock.

Clock

Continuously displays current time and is used for setting automatic brew time.

Auto Indicator Light

Light is on when waiting for automatic brew cycle to start.

Program Button

Used when setting automatic brew time. Press and hold while setting time.

On-Off Auto Switch

Starts the manual or automatic brew cycle.

Adjustable Cup Selector

Selects the amount of water to be used during brew cycle.


2 cup (9oz), 1/2 carafe (27oz), full carafe (54oz) amounts may vary.

Status Indicator light

Is on when brewing cycle is in process, blinks when detection sensor does not see a mug or carafe.

Hour/Minute Buttons

Used when setting clock and automatic brew time. Time advances automatically when buttons are held down.



PROGRAM DISPLAY PANEL

START UP

IMPORTANT:

Please read and follow instructions carefully before starting your BREW EXPRESS™ in-the-wall COFFEE SYSTEM.



Did you purge water lines during installation to remove any foreign particles (debris) in lines? Debris in water lines can clog brewer system causing failure, and VOID ALL WARRANTIES.



The BREW EXPRESS™ dispenses extremely hot water. Hot liquids may cause severe burns if it contacts skin. Use extreme caution when handling hot liquids dispensed by the BREW EXPRESS™. KEEP HANDS AWAY FROM SPRAY HEAD, BREW BASKET, CARAFE OR MUG DURING BREW CYCLE.

- 1.** Make sure water is “ON” prior to starting BREW EXPRESS™. The BREW EXPRESS™ will not operate if there is no water or water pressure is less than 30 psi.
- 2.** Make sure power is supplied to the BREW EXPRESS™. Power is supplied when the LED display is illuminated on the display panel.
- 3.** With the selector switch OFF, set clock by holding down buttons to advance hours, minutes noting the AM/PM indicator light.
- 4.** Flush brewing system by running two cycles of water through the brewer. Place brew basket under spray head without coffee or filter, place empty carafe under brew basket, select a full carafe, and move the switch from OFF to ON. After brewing cycle is complete, empty carafe and repeat.
- 5.** Wash carafe and brew basket with warm soapy water.

IMPORTANT REMINDERS

- Always empty carafe prior to starting the unit, otherwise overflowing can occur.**
- Use appropriate brew basket with carafe and mug.**



Brew Basket
with Stopper



Brew Basket
without Stopper

1. Set Clock

Time advances when hour/minute buttons are held down, note AM/PM indicator.

2. Set Up Brew Basket

For brewing into the carafe use the brew basket with the Pause-N-Serve stopper. For brewing into a mug use the brew basket without the stopper. Place a No# 10-12 flat bottom filter into the brew basket. Add desired amount of coffee for taste preference. Typically, use 1 tablespoon for each cup. Place brew basket into BREW EXPRESS™. **WARNING: BE CERTAIN BREW BASKET IS COMPLETELY INSERTED, OTHERWISE PROBLEMS MAY OCCUR SUCH AS EXCESS STEAM OR OVERFILLING**

3. Position Carafe or Mug

Position an **EMPTY** carafe or mug in the BREW EXPRESS™ under the brew basket outlet hole. The detection sensor will not allow the brewer to operate unless the carafe or mug is positioned under the brew basket. The brew light on the display panel will blink if nothing is detected. The sensor is designed to recognize a variety of materials. The sensor may not detect a mug that is flat black. If this occurs, use a different colored mug.

WARNING: ALWAYS EMPTY CARAFE OR MUG PRIOR TO STARTING THE UNIT OR OVERFILLING WILL OCCUR.

4. Select the Volume

Select the amount of coffee to be brewed by rotating the adjustable cup select to the desired amount to be dispensed from the BREW EXPRESS™. 2-cup (9oz), 1/2 carafe (27oz), full carafe (54oz) amounts may vary.

5. Manual Brew Cycle

To manually start a brew cycle move the slide switch from OFF to ON. If the switch is already in the ON position, switch it to the OFF position and then back to ON. The brew light will turn on once the cycle has started. If brewer is cold, the heater will preheat the water before starting the brew cycle. After the selected amount of water is dispensed, the brew light will remain on until all liquid has drained. At that time the the BREW EXPRESS™ will beep five times.

6. Automatic Brew Cycle

To automatically start a brew cycle set the automatic brew clock. Hold down the program button and press the minute / hour buttons until the desired time (am or pm) is displayed. Slide switch to the auto position. Place carafe or mug into the BREW EXPRESS™ under brew basket. The brew cycle will start automatically at the preset time.

NOTE: AUTOMATIC BREW CYCLE WILL NOT START IF THE CARAFE OR MUG ARE NOT PROPERLY IN PLACE.

7. Pause-N-Brew Feature

The BREW EXPRESS™ carafe can be removed during brew cycle to pour a cup of coffee. The detection sensor will stop the flow of water and the valve on the brew basket will prevent existing water from spilling. Once carafe is returned operation will continue. If carafe is missing for over 5 minutes BREW EXPRESS™ will shut off automatically.

MAINTENANCE

Cleaning

Carafe

Clean the carafe and lid after each use with warm water and a mild dish soap.

Brew Basket

The brew basket should also be cleaned after each use with mild dish soap and warm water.
The brew basket is dishwasher safe.

Spray Head

It is recommended the spray head be cleaned occasionally with mild soap and warm water depending on the amount of use. When the unit is cool, remove the spray head by gently rotating it by hand counter clockwise. After cleaning reinstall the spray head, hand tighten only. Be careful not to damage spray head.

Brewer Exterior

Clean the exterior of the brewer with a soft damp cloth. Avoid getting excessive water around the display panel and detection sensor. DO NOT use abrasive cleansers, they will damage the surface of the brewer. Be careful when using stainless cleaner or polish around plastic parts.

Removing Brewer from Wall

If brewer must be removed from wall for repair or cleaning. Follow this procedure.

1. Place cardboard or towel on counter in front of brewer to protect counter surface.
2. Remove screws (4) from the sides of brewer.
3. Firmly grab side edges of brewer with both hands and gently pull straight forward until brewer moves approximately 1".
4. Gently rotate the left side of brewer (display panel side) away from the wall until there is sufficient room to reach inside the rough-in-box.
5. Carefully reach behind brewer and disconnect the water supply line by pressing on the gray button on the connector from the water line to the brewer.

Display is not illuminated

- Ensure the power to the rough-in box is turned on (check circuit breaker).
- Ensure brewer is fully pressed into the rough-in box.
- Ensure the outlet inside the rough-in box is properly wired. Remove the brewer and check outlet with volt meter. If power is on and no voltage is detected at the outlet, wiring is incorrect. Turn off power. Remove power panel cover (two screws) and check wire source connection.
- Check wire connection at source.

Water does not flow from spray head

- If the BREW EXPRESS™ has not been used for 30 minutes or longer, it will PREHEAT the water for 30 seconds. You may be waiting for the preheat cycle to end.
- Ensure water has been turned on to the BREW EXPRESS™ (check valve at source).
- Ensure the carafe or mug is centered under the brew basket. BREW EXPRESS™ will not start if the detection sensor does not see a carafe or mug. Status light will blink. The detection sensor may not see a flat black or clear surface. If mug or carafe is flat black or clear, then switch to a different type of container.
- Ensure the water line is properly connected inside the rough-in box. Remove The four mounting screws on the side and pull out brewer. Check for pinched or kinks in the water supply line. The quick connector from the brewer must be pressed securely into quick connector from from water source.
- Ensure the water pressure is adequate. The BREW EXPRESS™ will not operate if water pressure is under 30 PSI. LED display will flash EEEE if water pressure is too low.
- Check the water filter (if present) at the supply. If filter is clogged replace filter.
- If problem persist and there is no filter in the water line, then coffee system maybe clogged by debris. Contact dealer or Lance Larkin™ for service. 1(866)268-5953

PARTS & SERVICE

Spare parts are available only from your dealer or direct from Lance Larkin™. Contact local dealer for all service and warranty issues.

- Spray head
- Brew Basket(s)
- Carafe and lid
- Mounting screws
- Auxiliary water pump and (5) gallon jug.
For installation in areas without water supply.

2 YEAR LIMITED WARRANTY

This limited warranty is the only one that applies to this product, and sets forth all the responsibilities of Lance Larkin™ regarding this product. There is no other warranty, other than that described herein.

BREW EXPRESS™ is warranted, to the original purchaser only, to be free of defects in parts and labor for 2 years from the date of purchase. This warranty does not extend to subsequent purchasers or users. Lance Larkin® will not be held responsible for any amount of damage in excess of the retail purchase price of the BREW EXPRESS™ coffee system under any circumstances. Incidental and consequential damages are specifically excluded from coverage from this warranty.

The BREW EXPRESS™ coffee system is not intended for commercial food service use. This warranty does not apply to accessories or damage to unit from misuse or incorrect installation. Misuse includes uses such as incorrect wiring or power supply installation, damage from incorrect filter or water line installation, and improper maintenance or use. It is further noted than non-use of filter or filtered water system (entire house) in hard water use areas will not be warranted.

RETURN/REPAIR POLICY: Any BREW EXPRESS™ unit other than accessories found to be defective may be returned postage paid to Lance Larkin®. Any defective BREW EXPRESS™ unit other than accessories returned to Lance Larkin™ within 1 year from the original date of purchase will be replaced free of charge. Any unit returned to Lance Larkin® more than 1 year after the original purchase date but less than 2 years from the original purchase date, Lance Larkin™ will repair the unit. The repaired or replaced unit will then be warranted under the terms of the remainder of the warranty period. The customer is responsible for all shipping charges of returned units. During the warranty period Lance Larkin™ will be responsible for the return one way shipping charges.

LIMITATIONS: This warranty does not cover accessories, brew baskets, carafe or defects resulting from normal wear and tear including chips, scratches, abrasions, discoloration due to improper care, neglect and abuse, accidents, damage during shipping to our service facility, unauthorized repair or alterations, failure to follow instructions for installation, operation and maintenance.

STATE LAW RIGHTS: This warranty gives you specific legal rights. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitations of Incidental or consequential damages, so the inclusions or limitations stated herein may not apply. This warranty gives the purchaser specific rights; other rights witch vary from state to state may also apply.

REQUEST FOR WARRANTY SERVICE: Contact Lance Larkin™ Technical Support by telephone, fax or mail. We suggest that you keep the original packaging in case it may be necessary to ship the unit. When returning the unit include you name, address, phone number, and dated sales receipt, (or copy) along with product serial number and description of the reason for return.

WARRANTY ACTIVATION: Please complete warranty card and mail to Lance Larkin™ for activation within 30 days of purchase along with a copy of dated sales receipt. BREW EXPRESS™ warranty card must be registered within 30 days to activate warranty. Mail completed card to:

Lance Larkin™
2700 NW Front Avenue
Portland, Oregon 97210
(866) 268-5953

WWW.BREWEXPRESS.COM

LANCE  LARKIN™

L I F E M A D E S I M P L E™